

**Eletta flow** 

when you want to know

# **Specifications PR1**

### **Function**

The Eletta PR1 Paddle Switch is using the liquid flow to activate the spring supported paddle and the micro-switch to give an alarm if the flow stops or starts.

PR1 can be used in pipe sizes from DN50 to DN250 and the set point is dependent on the length of the paddle and the pipe size, please refer to the table below.

The installation is simple as you can cut the paddle to the desired length on site according to the actual pipe size. The paddle aligns fully with the flow and creates a very small pressure drop. The function works only in one flow direction. Wetted parts is made of Copper Alloy and Stainless Steel and the sealing of Nitrile (HNBR).

# Specification

| Wetted material<br>Sealing Material | Copper Alloy and 316 SS<br>Nitrile (HNBR) |
|-------------------------------------|---|
| Max. pressure                       | 25 bar                                    |
| Max. temperature                    | +125°C (257°F)                            |
| Min. temperature                    | -20°C (-4°F)                              |
| Protection class                    | Standard IP43                             |
|                                     | Option IP65                               |
| Process connection                  | 25 mm thread (1" BSP)                     |
|                                     | (through pipe wall)                       |
| Pipe Sizes                          | DN50-DN250                                |
| Switch                              | Microswitch SPDT                          |
| 10-02                               | 1-pole 2-way                              |
|                                     |   |


| _   |       |      |    |       |
|-----|-------|------|----|-------|
| Fun | ction | test | in | water |

250 VAC 16 A

48 VDC 0,2 A 110 VDC 0,02 A

24 VDC 1 A


| Dimension | Switch-on<br>value<br>I/min appr. | Switch-off<br>value<br>I/min appr. |
|-----------|-----------------------------------|------------------------------------|
| DN 50     | > 125                             | < 75                               |
| DN 65     | > 150                             | < 100                              |
| DN 80     | > 200                             | < 150                              |
| DN 100    | > 300                             | < 200                              |
| DN 150    | > 350                             | < 250                              |



| Max Length Paddle Pipe sizes L mm |     |     |  |  |
|-----------------------------------|-----|-----|--|--|
| 2"                                | 50  | 22  |  |  |
| 2 1/2"                            | 65  | 38  |  |  |
| 3"                                | 80  | 52  |  |  |
| 4"                                | 100 | 75  |  |  |
| 5"                                | 125 | 100 |  |  |
| 6"                                | 150 | 125 |  |  |
| 8"                                | 200 | 175 |  |  |
| 10"                               | 250 | 200 |  |  |

## **Mounting**

The PR1 is position dependent and can only be mounted in a horizontal pipe with the connection box in an upward position. Please make sure that the flow direction is according to the arrow placed inside the connection box. A straight run free from bends and valves of 3 pipe inner diameter up- and downstream is recommended for proper function.



When installing make sure that the flow direction is in accordance with the arrow.



Breaking capacity at

inductive or resistive

load

22 222 1576 | 22 222 2745 | 9 982 72 932 info@scandimex.cl | www.scandimex.cl Avda. Lib. Bdo. O'Higgins 240, of. 81. Santiago



**FLOW MONITORS** 

#### **Eletta Flow AB**

Box 5084, SE-141 05 Huddinge, Sweden Tel. +46 8 603 07 70 • Fax. + 46 8 646 10 40